



Unmetered-Supplies-Operational-Charge-Codes VERSION 23.1 as at 16 July 2014

Nominal Watts	Unit Description 1	Manufacturer's Designation	Serial Nos	New Charge Code	Amendment Notes
7	Microwave Vehicle Detector	AGD 200 Microwave Vehilcle Detector		79 07 007 000 100	End-dated due to duplication, new charge code 7907007001100
7	Vehicle Detector	AGD 200 Microwave Vehilcle Detector	from S/No. -24826 to -32107	79 07 007 000 100	
7	Microwave Vehicle Detector	AGD 200 Microwave Vehilcle Detector		79 07 007 001 100	New Charge Code
3	Microwave Vehicle Detector	AGD 206 Microwave Vehicle Detector		79 07 003 000 100	
3	Microwave Vehicle Detector	AGD 206 Microwave Vehicle Detector		79 07 003 000 100	No Change
3	Vehicle detector	AGD 206 Microwave Vehicle Detector	from S/no. -00004 to -05657	79 07 003 000 100	
2	Vehicle detector	AGD 206 Microwave Vehicle Detector	from S/No. -05658 onwards	79 07 002 001 100	
7	Pedestrian Detector	AGD 220 Microwave Pedestrian detector - On Crossing	from S/No. 16447 to -28829	79 52 007 000 100	
2	Microwave Pedestrian On Crossing Detector	AGD 226 Microwave Pedestrian On Crossing Detector	from S/No. -00029 onwards	79 52 002 000 100	
1	Vehicle detector	AGD 307-5xx-xxx	from S/No. -00001 onwards	79 07 001 004 100	
3	Vehicle detector	AGD 316-5xx-xxx	from S/No. -00036 onwards	79 07 003 002 100	
4	Vehicle Detector	AGD 316-3xx-xxx	from S/No. -00049 onwards	79 07 004 003 100	
3	Vehicle Detector	AGD 318-5xx-xxx		79 07 003 005 100	
3	Pedestrian Detector	AGD 620 Digital Vision Pedestrian Detector - Kerbside	from S/No. -00391 to -09144	79 52 003 000 100	
4	Pedestrian Detector	AGD 625 Digital Vision Pedestrian Detector - Kerbside	from S/No. 01172 to -09428	79 53 004 000 100	
3	Digital Vision Pedestrian Detector	AGD 640 Digital Vision Pedestrian Detector	from S/No. -00014 onwards	79 52 003 001 100	End dated due to code change, replaced by 7953003000100
3	Digital Vision Pedestrian Detector	AGD 640 Digital Vision Pedestrian Detector	from S/No. -00014 onwards	79 53 003 000 100	Replaces 7952003001100
0.48	Pedestrian Control	AGD 921 Push Button Unit		79 38 001 000 100	Withdrawn by manufacturer
13	Pedestrian Control	AGD 920 / 940 PUFFIN Near Side Pedestrian Signal		79 39 013 000 100	
13	Pedestrian Control	AGD 920 PUFFIN Near Side Pedestrian Signal	from S/no. -06723 to -08837	79 39 013 000 100	
11	Pedestrian Control	AGD 924 PELICAN Pedestrian Signal		79 39 011 000 100	
11	Pedestrian Control	AGD 924 PELICAN Pedestrian Signal	from S/No. -00001 to -01661	79 39 011 000 100	
9	Pedestrian Control	AGD 924 PELICAN Pedestrian Demand Unit & Wait Signal	from S/No. -01662 to -04241	79 39 009 002 100	Adjusted Circuit data
9	LED Wait Signal/Push Button (dimmed)	AGD 924 PELICAN Pedestrian Demand Unit & Wait Signal	from S/No. -04242 onwards	79 39 009 003 100	
13	Pedestrian Control	AGD 940 PUFFIN Near Side Pedestrian Signal	from S/no. -00002 to -01202	79 39 013 000 100	
9	LED Pedestrian Nearside Signal/Push Button (dimmed)	AGD 940 PUFFIN Nearside Pedestrian Signal	from S/No. -01203 onwards	79 55 009 002 100	Adjusted Circuit data
8	Pedestrian Control	AGD 941 Pedestrian Demand Unit		79 39 008 000 100	
8	Pedestrian Control	AGD 941 Pedestrian Demand Unit	from S/no. -00001 to -03282	79 39 008 000 100	
4	Pedestrian Control	AGD 941 Pedestrian Demand Unit	from S/No. -03283 to -10312	79 39 004 000 100	Rounded Circuit Watts, VA and Var
4	LED Wait Signal/Push Button (dimmed)	AGD 941-66x Pedestrian Demand Unit	from S/No. -10313 onwards	79 39 004 001 100	Adjusted Circuit data
15	LED Pedestrian Nearside Wait Signal/Push Button (dimmed)	AGD 942 Toucan Near side Pedestrian Signal		79 55 015 000 100	
12	LED Pedestrian Nearside Signal/Push Button (dimmed)	AGD 942 Toucan Nearside Pedestrian Signal	from S/No. -00527 onwards	79 55 012 000 100	
22	Pedestrian Control	AGD 946 Combined PUFFIN Near Side Pedestrian Signal		79 55 022 000 100	
22	Pedestrian Control	AGD 946 Combined PUFFIN Near Side Pedestrian Signal	from S/No. -00431 to -02895	79 55 022 000 100	
13	LED Pedestrian Nearside Signal/Push Button (dimmed)	AGD 946 Combined PUFFIN Near Side Pedestrian Signal (Integral Push Button)	from S/No. -02896 to -08799	79 55 013 000 100	Adjusted Circuit data
13	LED Pedestrian Nearside Signal/Push Button (dimmed)	946 Combined PUFFIN Near Side Pedestrian Signal (Integral Push Button)	from S/No. -08800 onwards	79 55 013 001 100	Adjusted Circuit data
23	LED Pedestrian Nearside Wait Signal/Push Button (dimmed)	AGD 947 Combined Toucan Near side Pedestrian Signal		79 55 023 000 100	
23	LED Pedestrian Nearside Wait Signal/Push Button (dimmed)	AGD 947 Combined Toucan Near side Pedestrian Signal	from S/No. -00001 to -00884	79 55 023 000 100	
16	LED Pedestrian Nearside Signal/Push Button (dimmed)	AGD 947 Combined Toucan Near side Pedestrian Signal (Integral Push Button)	from S/No. -00885 to -03067	79 55 016 000 100	
16	LED Pedestrian Nearside Signal/Push Button (dimmed)	AGD 947 Combined Toucan Near side Pedestrian Signal (Integral Push Button)	from S/No. -03068 onwards	79 55 016 001 100	Adjusted Circuit data
11	LED Wait Signal / Push Button (dimmed)	SA-146	from S/No. -00001 onwards	79 39 011 001 100	Adjusted Circuit data